

CAUTION

PLEASE READ BEFORE CHARGING

1. REMOVE BATTERY PLUG AND CHECK FUSE VALUE BEFORE AT THE BOTTOM OF THE UNIT.
2. CHARGE FOR 24 HOURS ALWAYS WHEN BATTERIES ARE COMPLETELY DISCHARGED.
3. UNPLUG CORDS FROM OUTLET BEFORE REMOVING BATTERY PLUG FROM PLUG.
4. WAIT AT LEAST 24 HOURS AFTER DISCHARGING CHARGER BEFORE CHARGING UNIT.
5. CHARGER SHOULD BE ATTENDED ONLY BY PROPERLY TRAINED PERSONNEL AND OPERATING MANUALS.

DIVER RECALL SYSTEM DRS-100

ON

OFF



GO DOWN DUCK

DIVER GROUP



HOLD DOWN 30 SECS AND REPEAT

LINE IN



12PM
BATT

24 VOLT



EXT. BATT/CHRG

OFF



ALARM



POWER



SIGNAL